


Quick Start Card

HF3471



Clock time / Hora del reloj / Heure (horloge)





Alarm time / Hora de la alarma / Heure (alarme)

Alarm sounds / Sonidos de la alarma / Sons d'alarme

Dusk simulation / Simulación del anochecer / Simulation de crépuscule

Display brightness / Brillo de la pantalla / Luminosité de l'affichage

PHILIPS



4

